MULTIBECK

USING WITH BROILERS

BEFORE CHICKS ARRIVE

 Turn the upper pan ³/₄ to 1 turn from lower pan



- ► Turn on the feed line
- Distribute the feed by slightly shaking the feeder

BROILER'S BACK → LEVEL WITH LOWER PAN EDGE

(The neck of the bird should be slightly outstretched when eating)



